




***APPLICATION** GUIDE*

BLACK BOX
PROFESSIONAL HORTICULTURE CONTROLS

ROOM ICONS




START SCREEN/ACTIVE ROOM

The room icon indicates graphically the status of any given room/zone. This icon provides a clear visual signal of whether a room is active, if the lights are on or off, and if any environmental conditions are outside of set parameters.

- ALL GREY**
Inactive room.
- ALL GREEN**
Active room with no alarms and lights off.
- GREEN WITH YELLOW ROOF**
Active room with no alarms and lights on.
- RED WITH GREEN ROOF**
Active room with alarm conditions and lights off.
- RED WITH YELLOW ROOF**
Active room with alarm conditions and lights on.

ENVIRONMENTAL ICONS



ROOM SUMMARY

The environmental icons communicate conditions within the grow space. Individual parameters can be set for each room/zone to allow for alarms to inform growers if temperature, humidity, CO2 or VPD levels are measured either higher or lower than the set parameters. Up to three sensors can be connected to each LPDP.

- TEMPERATURE**
Correct temperatures are critical for proper plant growth. Ambient temperature is measured from 32°F to 122°F (0°C to 50°C ±1°C).
- CO₂**
Maintaining proper CO₂ levels increases product yields and qualities. The Growlite Black Box Sensor (P/N GLC-BBTHCS Temp, Humidity, CO₂ Sensor) measures CO₂ levels up to 10,000 ppm ±30 ppm.
- RELATIVE HUMIDITY**
Managing humidity within a grow space is necessary to maintain rigorous growth and mitigate mold and mildew. A capacitive polymer sensor samples the ambient air and provides 0% to 99% RH readings within ±2.5%.
- VPD**
Vapor Pressure Deficit measures the difference between the amount of moisture in the air and the total amount of moisture the air can potentially hold. A lower VPD opens a plant's stomata and supports higher transpiration rates, a higher VPD closes stomata and limits transpiration.
- LAMP HOUR**
A time counter that keeps a running track of the number of hours the lamps have been running to aid in re-lamping at the appropriate times.
- CYCLE DAY**
This timer keeps track of the cycle day for a particular room/zone and can be reset when a new crop is installed.

ROOM SUMMARY ICONS



LIGHT TIMING, NOTES AND SETTINGS

- LIGHT**
Access to the light timing controls for the room/zone:
 - Shortcut timing buttons for 0/12/18/24 hour light cycles with ability to enter the on time.
 - A Custom Hours timing button to allow users to enter custom time cycles with the ability to enter the on and the off time.
 - A button to manually turn the lights off in room/zone.
- NOTES**
Logs communication between the room/zone operator and the head cultivator/facility manager regarding the specific day-to-day information for the room/zone.
- SETTINGS**
Screen to allow users to customize the room/zone, including:
 - Define the environmental parameters for the room/zone (Temp, RH, CO₂, VPD).
 - Name the room/zone and the product.
 - Start/re-start the Cycle Day counter.
 - Zero the Lamp Hour counter.
 - Disable the alarm functions.

ADMINISTRATION ICONS



- EMAIL**
Allows administration to setup the email(s) that will be notified in the event of an alarm condition. Emails can be setup for each room/zone ensuring notifications are being sent to the appropriate personnel.
- LOGIN**
Users must login to make any changes to the light timing or environmental parameters.
- CLEAN**
A function that temporarily disables the touchscreen to allow for cleaning.
- EXIT**
Exit the Black Box OS and enter MS DOS.
- SET TIME**
Set current local time.
- ADD ROOM**
Add a room to your setup.
- SUBTRACT ROOM**
Subtract a room from your setup.
- BACKUP/LOAD**
Button to backup all room/zone settings and make updates to the system, then load them back into the system to avoid the need to manually re-enter the information.
- LOGOUT**
Button to logout of the system.



AUTOMATE THE FUTURE

BARRON[®]

7885 N Glen Harbor Blvd
Glendale, Arizona 85307
800.533.3948

MKT-LIT-GL-BB-APP
10840285 10/18

GROWLITE.COM