

## IMPORTANT SAFEGUARDS READ AND FOLLOW ALL SAFETY INSTRUCTIONS.

When using electrical equipment, basic safety precautions should always be followed including the following:

**DISCONNECT AC POWER SUPPLY BEFORE SERVICING.**

- Installation and servicing of this equipment should be performed by qualified service personnel only.
- Ensure that the electrical wiring conforms to the National Electrical Code NEC® and local regulations if applicable.
- Do not mount near gas or electric heaters.
- Equipment should be mounted in locations and at heights where it will not be readily subjected to tampering by unauthorized personnel.
- The use of accessory equipment not recommended by the manufacturer may cause an unsafe condition.
- Any modification or use of non-original components will void the warranty and product liability.
- Do not use this equipment for other than intended use.

**SAVE THESE INSTRUCTIONS!**



### INSTALLATION INSTRUCTIONS

1. Prepare mounting of fixture by either V-Hook or Cable Hanger.

**Note:** WBV fixtures are not suitable for surface mounting

**A. V-HOOK**

1. Insert V-Hook through the last link on one end of each jack chain.
2. Insert V-Hook into slotted holes located at each end of the housing.
3. Attach opposite ends of the jack chain to appropriate ceiling mounted eyelets or anchors at the desired height.

**B. CABLE HANGER**

1. Insert toggles into holes located at each corner of the fixture, there should be two sets of Y-toggles, one for each end of the fixture. Make sure toggles are extended and secure before hanging fixture.
2. Hook the eyelets at the other ends of the Y-toggle cables onto the appropriate anchors or hooks. Optional straight cables are available, consult factory.

2. Connect extension cord wire assembly to the corresponding neutral, ground and 120V wires inside fixture wiring compartment.
3. Slide cover with strain relief and cord into the body of the WBV and use screw provided to secure cover.
4. Connect power cord to 120VAC outlet.
5. For 240VAC or 277VAC inputs consult a qualified electrician.

## OPERATION

The WBV requires no special handling, power ON or power cycle requirements. We recommend routine inspections to visually verify the fixture is ON and emitting light. Refer to the troubleshooting guide for any unit not functioning correctly.

## TROUBLESHOOTING

If the WBV does not turn ON:

1. Check incoming voltage to the LED driver. Must be at least a minimum of 120VAC and not to exceed 277VAC.
2. If all LEDs on the engine are OFF, LED driver may be disconnected. Ensure driver(s) are secure. If secure, use voltmeter to check voltage is present at the output of the power supply. If low or no voltage, consult factory.
3. If some, but not all LEDs are working consult factory for additional technical support. Please have the catalog number and photos available when contacting technical support.